




FASE N°1 OPEN THE HOOK AND POSITION OVER THE CONTAINER TO GRIP THE OUTER RING




FASE N°2 CLOSE THE HOOK, VISUALLY ENSURING THE RING IS SECURED INSIDE THE HOOK, AND BEGIN THE LIFTING PHASE




FASE N°3 LIFT THE WASTE CONTAINER OFF THE GROUND AND POSITION IT INSIDE THE SKIP




FASE N°4 REOPEN THE HOOK AFTER PLACING THE WASTE CONTAINER ON THE BOTTOM OF THE SKIP




FASE N°5 POSITION OVER THE WASTE CONTAINER TO GRIP THE CENTRAL RING WHICH ALLOWS THE OPENING OF THE CONTAINER



FASE N°6 CLOSE THE HOOK, ENSURING THE RING IS SECURED INSIDE THE HOOK, AND BEGIN THE LIFTING PHASE



FASE N°7 USING THE CENTRAL RING DURING THE LIFTING PHASE, YOU WILL NOTICE IT EXTENDING, THUS GIVING THE OPENING COMMAND



FASE N°8 REOPEN THE HOOK AFTER PLACING THE CONTAINER ON THE GROUND IN THE DESIRED POSITION, COMPLETING THE LOADING PHASE

